


## Carbureted Fuel Pressure Regulator Installation Instructions



- 1 The regulator is designed with a threaded adjuster and locking nut at the top which alters the preload on the internal spring. Increasing the preload will increase the fuel pressure.
- 2 Pressure port for attaching a fuel pressure gauge or sensor.
- 3 Outlet. O-Ring should be facing the regulator side.
- 4 Inlet